

Safety information



This product and plastic bag could be a choke hazard, **please keep out of reach of children.**

Please contact your supplier if any of the components appear damaged or faulty.



This product is designed to be used in an indoor, domestic environment only.



To protect the environment, this product must be disposed of appropriately and safely at the end of its life.



This product is CE approved.



This product complies with RoHS regulations.

RF transmitter information

This device operates at radio frequencies in the range 2.4000GHz to 2.4835GHz (2.4GHz WiFi). The transmit duty cycle is less than 1%. The peak emitted power does not exceed 100mW.

Manufacturer: Green Energy Options Ltd.
Hardwick, Cambridge, CB23 7QS, UK



SM2D-A-QSG-001

WiFi Module

Quick start guide

About the WiFi Module

The WiFi module has been provided to plug into your Trio Touch button display. This will give you access to your energy data within your energy app.

Compatibility

This WiFi Module is compatible with:

- Trio Touchbutton

It cannot be used on any other Trio.

Installation

What you will need:

- The Wifi Module
- A small flat bladed screwdriver

Instructions

If your Trio has been supplied with the optional WiFi module, or you have received this subsequently, please follow the instructions below to insert the new module.

1 Removing the blank plate

Make sure the display is disconnected from the power supply and any batteries are removed, then remove the panel from the rear of the display (use a small flat bladed screwdriver and lever up from the left-hand side gently).



Please safely discard the removed plastic panel in an appropriate recycling bin or facility.



2 Inserting the WiFi Module

Take the WiFi module out of its packaging. Make sure the module is the right way up (see image). When inserting, place the left-hand side down first, then push down (**without excessive force**) on the right-hand side until it clicks into place.

If the WiFi network and menu item is not visible in the settings menu, then the Wifi Module is not present or has not been inserted incorrectly.

3 Connecting your Trio to your App

Please follow the instructions in your energy app.

CAUTION: This product and plastic bag could be a choke hazard, please keep out of reach of children.